


Maytag AAV7000AJW 01 - BASE & MOTOR



Maytag [Residential Maytag AAV7000AJW Washer Parts](#) Parts Diagram 01 - BASE & MOTOR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35-2065			Pad, Motor Plate
2	21001632			Motor
3	25-7733	681414		Screw, 10AB X 1/2
4	21001598			Spring, Suspension
5	21001110	22004376		Spring, Motor Pivot
6	35-3646			Isolator, Motor Plate
7	25-7831			Spacer, Mounting
8	25-7830			Spacer
9	35-3570			Washer, Motor Pivot
10	33-9946			Isolator, Motor
11	35-3571			Slide, Motor Pivot
12	25-7047			Washer, Flat
13	33-9967			Washer, Motor Isolator
14	21002009	Y707702		Locknut
15	21001833			Pulley, Motor
16	35-2279			Belt, Drive

17	21002254	285655	Clamp, Hose
"	25-6068	285655	Clamp, Hose
18	21001915		Hose, Tub To Pump
19	21002219	35-6780	Pump-Water
20	21001833		Pulley, Motor
21	35-2132		Washer, 1.25ODX.530IDX.032
22	12002213		Thrust Bearing Kit
23	21001486		Foot Slide, Isolator
24	21002221		Stabilizer Bar Kit
25	25-7828	489483	Screw 10-32 X 1/2
26	21001893	12002701	Base Kit
27	25001119		Foot And Pad Assembly
28	53-0120		Clip, Front Panel
29	21001366	21001783	Plate And Screw Assembly

