


Maytag AED4470TQ0 02 - TOP AND CONSOLE PARTS

TOP AND CONSOLE PARTS

For Models: AED4470TQ0
(White)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

W10115600

3

[Maytag Residential Maytag AED4470TQ0 Dryer Parts](#) Parts Diagram 02 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8274261			Do-It-Yourself Repair Manuals
2	3401684			Jumper, Wire
3	693995			Screw, Hex Head
4	8579674	8579686		Endcap
5	8312709			Clip-Console
6	388326			Screw, 8-18 X 1.25
7	694419			Mini-Buzzer
8	8579673	8579685		Endcap
9	3399639			Switch, Rotary Temperature
10	8558463			HANDLE AND LINT SCREEN ASSEMBLY
11	8536939			Clip, Knob
12	8533971	90767		Screw, 8A X 3/8 HeX Washer Head TAPPING
13	688983	487240		Screw, For Mtg. SERVICE CAPACITOR
14	8533951	3400859		Screw, Grounding

15	3395683		Receptacle, Multi-Terminal
16	8559800	8563663	Top
17	W10110063		Knob, Control
18	3394427		Clip-Harness
19	W10110066		Knob, Push-To-Start
20	3401144		Connector
21	3979617		Timer, 60 Hz
22	W10086678		Panel, Control
23	8539893		Wire, Jumper
24	8579678		Bracket, Control
25	W10110064		Timer Knob Assembly
26	3936144		Do-It-Yourself Repair Manuals
27	3398095		Switch, Push-To-Start
28	94614		Terminal
29	3347243		Block, Disconnect
30	357213		Nut, Push-In
31	8576503		Harness, Wiring
33	3397269		Connector, Timer

