


Maytag AED4475TQ1 01 - TOP AND CONSOLE PARTS



1-09 Litho In U.S.A. (LT) (psw)

1

Part No. W10250587 Rev. A

Maytag [Residential Maytag AED4475TQ1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10150636		Not Available	Guide, Use & Care
"	W10150612		Not Available	Instructions, Installation
"	W10150668		Not Available	Sheet, Cycle Feature
"	W10185979			Wiring Diagram Cycle Feature
2	693995			Screw, Hex Head
3	W10141666			Panel, Control
4	8271365	279962		Endcap
5	3936144			Do-It-Yourself Repair Manuals
6	388326			Screw, 8-18 X 1.25
7	8533951	3400859		Screw, Grounding
8	8271359	279962		Endcap
9	8274261			Do-It-Yourself Repair Manuals
10	8557857			Screen, Lint
11	688805			Clip, Spring Knob
12	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
				Screw, For Mtn. Service

13	688983	487240	Screw, For Mtg. Service Capacitor
14	8536939		Clip, Knob
15	3395683		Receptacle, Multi-Terminal
16	8557930	8563985	Top
17	8538959		Knob, Push-To-Start
18	3394427		Clip-Harness
19	3391249		Cable Tie, Push Mount
20	94614		Terminal
21	W10185972		Timer, 60 Hz
22	357213		Nut, Push-In
23	W10186068	W10186166	Harness, Wiring
24	3977456		Switch, Push-To-Start
25	8538953		Timer Knob Assembly
26	8271418		Bracket, Control

