


Maytag AGD4475TQ0 01 - TOP AND CONSOLE PARTS



Maytag [Residential Maytag AGD4475TQ0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10088774		Not Available	Guide, Use & Care
"	W10088971		Not Available	Instructions, Installation
"	8576793		Not Available	Wiring Diagram
"	W10089174		Not Available	Sheet, Cycle Feature
2	693995			Screw, Hex Head
3	3397269			Connector, Timer
4	8271365	279962		Endcap
5	3936144			Do-It-Yourself Repair Manuals
6	3395683			Receptacle, Multi-Terminal
7	8271359	279962		Endcap
8	357213			Nut, Push-In
9	8274261			Do-It-Yourself Repair Manuals
10			Not Available	
11	8536939			Clip, Knob
13	688983	487240		Screw, For Mtg. Service Capacitor
14	388326			Screw, 8-18 X 1.25

15	3394427		Clip-Harness
16	8557930	8563985	Top
17			Not Available
18	94614		Terminal
19	8533951	3400859	Screw, Grounding
21	8299764		Timer Assembly, 60 Hz
22	3391249		Cable Tie, Push Mount
23	8299876		Harness, Wiring
24	3403499		Connector, 2-Position
25	3403498		Connector, 3-Position
26	8533971	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
27	3977456		Switch, Push-To-Start
28	8538953		Timer Knob Assembly
29	8271418		Bracket, Control
30	W10141666		Panel, Control
31	717252		Receptacle, Terminal
32			Not Available

