


# Maytag AGD4475TQ1 01 - TOP AND CONSOLE PARTS

## Admiral

### TOP AND CONSOLE PARTS

For Model: AGD4475TQ1  
(White)

29" GAS DRYER



1-09 Litho in U.S.A. (MP)(bay)

1

Part No. W10247699 Rev. A

Maytag [Residential Maytag AGD4475TQ1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10160636		Not Available	Guide, Use & Care
"	W10150630		Not Available	LITERATURE PARTS INSTRUCTIONS, INSTALLATION
"	<a href="#">W10185979</a>			Wiring Diagram Cycle Feature
"	W10150668		Not Available	Sheet, Cycle Feature
2	<a href="#">693995</a>			Screw, Hex Head
3	<a href="#">3397269</a>			Connector, Timer
4	8271365	<a href="#">279962</a>		Endcap
5	<a href="#">3936144</a>			Do-It-Yourself Repair Manuals
6	<a href="#">3395683</a>			Receptacle, Multi-Terminal
7	8271359	<a href="#">279962</a>		Endcap
8	<a href="#">357213</a>			Nut, Push-In
9	<a href="#">8274261</a>			Do-It-Yourself Repair Manuals
10	<a href="#">8557857</a>			Screen, Lint
11	<a href="#">8536939</a>			Clip, Knob
12	688082	<a href="#">487240</a>		Screw, For Mtg. Service

13	<a href="#">000903</a>	<a href="#">907440</a>	Capacitor
14	<a href="#">388326</a>		Screw, 8-18 X 1.25
15	<a href="#">3394427</a>		Clip-Harness
16	8557930	<a href="#">8563985</a>	Top
17	<a href="#">688805</a>		Clip, Spring Knob
18	<a href="#">94614</a>		Terminal
19	8533951	<a href="#">3400859</a>	Screw, Grounding
21	<a href="#">W10185971</a>		Timer Assembly, 60 Hz
22	<a href="#">3391249</a>		Cable Tie, Push Mount
23	<a href="#">W10186074</a>		Harness, Wiring
24	<a href="#">3403499</a>		Connector, 2-Position
25	<a href="#">3403498</a>		Connector, 3-Position
26	8533971	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
27	<a href="#">3977456</a>		Switch, Push-To-Start
28	<a href="#">8538953</a>		Timer Knob Assembly
29	<a href="#">8271418</a>		Bracket, Control
30	<a href="#">W10141666</a>		Panel, Control
31	<a href="#">717252</a>		Receptacle, Terminal
32	<a href="#">8538959</a>		Knob, Push-To-Start

