


Maytag AGD4475TQ1 02 - CABINET PARTS

CABINET PARTS

For Model: AGD4475TQ1
(White)



W10247699

3

Maytag [Residential Maytag AGD4475TQ1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	697776	4331106		Screw, No.10-32 X 7/16
2	343641	681414		Screw, 10AB X 1/2
3	693995			Screw, Hex Head
4	8541400			Bracket, Cabinet
5	3396795			Cover, Terminal Block
6	3394975			Plug, Front Panel
7	3396805	280043		Panel-Rear
8	342055	488627		Screw
9	3980175			Clamp, Elbow
10	3406109	3406107		Door Switch Assembly
11	697773	3395530		Screw
12	3404413			Plug, Hinge Hole
13	3403630			Plug, Strike Hole
15	3394083			Clip, Front Panel
16	3392100	49621		Feet-Leveling
17	8066217			Hinge, Top

18	8530603	8533643	Cabinet
19	98234		Clip, U-Bend
20	690363	18776	Lock, Front Top
21	W10224855	W10248059	Panel
22	691366		Idler And Pulley Assembly
23	685203	279220	Clip
24	3389441		Door Catch Assembly
25	W10131364	341241	Belt
26	348780		Base, Motor
27	3400500		Bolt, 3405245 5/16-18 X 3/4
28	3405514	W10362431	Hinge And Pin Assembly
29	8066184		Pulley, Motor
30	W10194250	279827	Motor-Drve
31	W10121316		Plug, Multivent
32	3404162		Clamp, Motor
33	3403431		Strike, Panel
34	341029		Clamp, Pipe Door Spring
35	3402341		Door, Inner
36	3402335		Door, Front
37	8566059		Handle, Door
38	3406129		Seal And Bearing Assembly
39	344020	3401402	Cord, Power
40	3405246		Seal, Door Push-To-Start
41	8318272	W10465748	Burner-Gas

the laundry company[®]

the laundry company[®]