


# Maytag BA5000 02 - ORBITAL TRANSMISSION

SECTION: ORBITAL TRANSMISSION  
MODEL: ALL MODELS



Maytag [Residential Maytag BA5000 Washer Parts](#) Parts Diagram 02 - ORBITAL TRANSMISSION  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">207538</a>			Agitator W/Lock Screw
2	207153	<a href="#">6-2097820</a>		Kit- Shaft
3	206713	<a href="#">6-2067130</a>		Gear- Beve
4	215411	<a href="#">12001451</a>		Ctr Shaft W/Collar Andkeeper-Sha
5	215415		Not Available	COLLAR, LOWER
6	<a href="#">215721</a>			Dispensing Cap
7	<a href="#">215733</a>			Dispensing Cup
8	211059	<a href="#">6-2301530</a>		Pulley
9	<a href="#">Y207427</a>			Lint Filter Shallow
10	206602	<a href="#">207843</a>		Lip Seal Repair Kit
11	<a href="#">Y206629</a>			Pin, Collar
12	215401	<a href="#">W10221114</a>		Pinion
13	<a href="#">215395</a>			Plate, Clutch
14	<a href="#">210690</a>			Seal, Rubber
15	Y058700	<a href="#">675652</a>		Adhesive
16	<a href="#">215581</a>			Spring, Agitator Shaft

17	211375	<a href="#">681582</a>	Screw
"	<a href="#">211089</a>		Lug, Stop Pulley
18	206685	<a href="#">6-2066850</a>	Yoke
19	206708	<a href="#">6-2097790</a>	Transmison
20	215417	Not Available	SCREW, TRANSMISSION COVER
"	<a href="#">206628</a>		Cover, Transmission
21	206625	<a href="#">6-2097790</a>	Transmison
22	<a href="#">215394</a>		Washer, Bevel Gear
23	211090	<a href="#">22003555</a>	Washer, Stop Lug
24	211483	<a href="#">6-2114830</a>	Washer- SP

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>