


Maytag DE16CA 06 - FRONT VIEW

2

MODELS DE & DG16

SPECIFY COLOR IF OTHER THAN WHITE

FRONT VIEW



Maytag Residential Maytag DE16CA Dryer Parts Parts Diagram 06 - FRONT VIEW

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205470		Not Available	MAYTAG COIN SLIDE
2	300838			Lint Screen
3	301023			Lint Screen Retainer
5	301369		Not Available	SHAFT WITH SPIDER
6	301745	304299		Hinge - Upper
7	301746	Y304298		Hinge - Lower
8	302451			Hinge Assembly
9	302452			Door Liner
10	302453		Not Available	DOOR-WHITE
11	Y302455			Switch
12	302474		Not Available	CONTROL COVER-WHITE
13	302480		Not Available	LATCH
14	302525		Not Available	FRONT PANEL-WHITE
15	302539		Not Available	TOP COVER-WHITE
16	302567	302877		Pilot Light
17	Y302699	22003428		Leg, Adjustable

18	302954	Not Available	DRUM W/FELT - PORCELAIN
19	302984		Baffle Assembly - Poly
20	Y303204		Start Switch With Nuts
21	Y303224		Selector Switch
23	310217	Not Available	No Longer Available
24	310578	Not Available	WASHER
25	310579	Not Available	SCREW, No.10-24 X 11/16 INCH
26	Y310759		Screw, Tumbler Baffles
27	310768	Not Available	WASHER
28	Y311017		Retainer Spring
29	311412		Screw
30	311534		Felt Seal
31	311551		Clip For Door Harness
32	Y312060	Not Available	SHIELD FOR SPIDER----C
33	312233	Not Available	DRYING INSTRUCTION OVERLAY
34	312236	Not Available	PANEL-WHITE
35	312237	Not Available	PANEL-WHITE
36	312238		Door Seal
37	312239	Not Available	DOOR PANEL-WHITE
38	312249	Not Available	STRIKE PLATE
39	312251	Not Available	BACK FOR CONTROL PANEL
40	312255	Not Available	ANGLE FOR CABINET - DRYER
41	312269	Not Available	CONTROL PANEL
42	312271	Not Available	HANDLE
43	312311	312311MAY	Screw
44	312312	Not Available	INSULATION - DOOR
45	312477	Not Available	MAGNETIC LATCH RETAINER
46	312622	22001496	Front Panel Fastener And Screw
47	Y312702		Knurled Nut, Start Switch
48	Y312706	422617	Nut
49	Y312744		Door Panel-White
50	312751		Lockwasher, Start Switch
51	312754	31-2754	Minimanual
52	312802	Not Available	CONTROL PANEL
53	204051	22204051	Knob
54	204327	Not Available	COIN BOX-WHITE----NA
55	210385		Lock Nut For Adjustable Leg
56	210684		Foot, Adjustable Leg
57	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
58	212276	W10116760	Screw
59	212519	488234	Screw 8-32 X 1/4
60	213007		Xfor Cabinet See Cabinet, Back
61	213099		Lens For Control Panel
62	213322	Not Available	MAYTAG DECAL
63	213949		Screw, No.8-18 X 5/16 Inch
64	052792		Screw, 1 1/4-20 X 5/16
65	054151		Screw, No.4-40 X 1/4
66	214650		Screw For 2-4051 Knob