


Maytag DE16CA 10 - WIRING & CONTROLS



Maytag Residential Maytag DE16CA Dryer Parts Parts Diagram 10 - WIRING & CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y300896			No.2 Wire
3	301548			Clamp, Ground Wire
4	301552	305864		Thermostat Kit
5	302148		Not Available	No.4 WIRE W/RECEPTACLES GAS
6	Y302278			Motor
7	Y302455			Switch
8	302567	302877		Pilot Light
9	302575		Not Available	DOOR SWITCH HARNESS
10	302576	303344		Handledr
11	303035			Regulating Thermostat
12	303088		Not Available	GAS VALVE WIRES WITH PLUG
13	Y303204			Start Switch With Nuts
14	Y303224			Selector Switch
15	Y303225			Thermostat, Permanent Press
16	303226			Wire Harness For Door Switch

17	303227		Not Available	THERMOSTAT WIRE HARNESS
18	303228		Not Available	MAIN WIRE HARNESS
21	303291		Not Available	DOOR SWITCH HARNESS
24	303295	3367669		Protector, Edge
26	Y310376			Clip, Door Switch Harness
27	Y311916	22003781		Screw, Ground Strap
28	Y312209	W10001200		Screw
29	Y312702			Knurled Nut, Start Switch
30	Y312706	422617		Nut
31	312751			Lockwasher, Start Switch
32	Y201808			Converter
33	204051	22204051		Knob
34	211737	248562		Terminal
35	212519	488234		Screw 8-32 X 1/4
36	213099			Lens For Control Panel
37	400008			Block, Terminal
38	410351		Not Available	HARNESS RETAINER
39	Y052684	112432		Nut
40	054151			Screw, No.4-40 X 1/4

