


Maytag DE16CT 03 - CT CONTROL CENTER

10

SPECIFY COLOR IF OTHER THAN WHITE

MODELS DE & DG16

CT CONTROL CENTER



* SEE YOUR COMMERCIAL LAUNDRY DISTRIBUTOR FOR LOCKS AND KEYS.
 Copyright 1968 THE MAYTAG COMPANY • Newton, Iowa • Printed in U.S.A. (Revised 11-73)

Maytag Residential Maytag DE16CT Dryer Parts Parts Diagram 03 - CT CONTROL CENTER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y302559		Not Available	HARNES FOR TIMER
2	303010		Not Available	CONTROL CENTER COMPLETE
3	303014		Not Available	TIMER WITH KNOB AND PIN
4	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
5	201110		Not Available	WIRE CONNECTOR
6	202477	22003292		Control As
7	203188		Not Available	TIMER ACCESS DOOR (WHT)
8	203264		Not Available	OUTER CASE-WHITE
9	203278			Harness For Ticket Control
10	203307		Not Available	MTG. STRAP---NA
11	203310			Access Door-White
12	204006		Not Available	ACCESS DOOR-WHITE
13	204879		Not Available	HARNES FOR TICKET CONTROL
14	210294	910309		Washer, Mounting Strap

15	211168	W10139210	Screw, 8-18 X 5/16
16	212276	W10116760	Screw
17	212457	Not Available	PIN RECEPTICLE
18	212519	488234	Screw 8-32 X 1/4
19	213034		Gasket Under Control Center
20	213064		Front Plate F/Ticket Contro
21	213070	Not Available	BRACKET FOR TICKET ASSEMBLY
22	213641	Not Available	LATCH FOR ACCESS DOOR
23	Y052740	62739	Nut, Lock

