



Copyright 1968 THE MAYTAG COMPANY • Newton, Iowa • Printed in U.S.A. (Revised 11-73)

Maytag Residential Maytag DE16CT Dryer Parts Parts Diagram 04 - CT CONTROL CENTER COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
2	311612		Not Available	COVER, CIRCUIT BOARD TERMINALS
3	311613	Y311711		Screw, Fuse Block
4	201110		Not Available	WIRE CONNECTOR
5	202388		Not Available	CAM PLATE ASSEMBLY
6	202389			Switch For Ticket Control
7	202390		Not Available	SWITCH ACTUATOR
8	202399			Jumper Wire - Black
9	202477	22003292		Control As
10	202479	A3167501		Lamp Oven, Int.
11	202509			Ticket Control Assembly
12	202713	22001555		Fuse
13	203140			Contact Ball Kit
14	203186		Not Available	FUSE BLOCK WITH FUSE
15	203277		Not Available	LAMP SOCKET WITH

15	203277	Not Available	BRACKET
16	203278		Harness For Ticket Control
17	203357	Not Available	TICKET RECEIVER ASSEMBLY
18	212452		Board, Circuit
19	212457	Not Available	PIN RECEPICLE
20	212518	Not Available	SEMS SCREW, No.4-40 X 1/2 INC
21	212519	488234	Screw 8-32 X 1/4
22	212520	Not Available	SCREW-MICRO SWITCH
23	212533		SHIELD FOR HEAT LAMP
24	212534	Not Available	SCREW, SHIELD TO CONTROL
25	212849	Not Available	ROLLER FOR CAM
26	213064		Front Plate F/Ticket Contro
27	213070	Not Available	BRACKET FOR TICKET ASSEMBLY
28	213084	Not Available	TICKET DEFLECTOR
29	213137	Not Available	SCREW, No.6 X 1/4 INCH
30	213378		BLOCK & ELECTRONIC CONTROL)

