


Maytag DE18CA 03 - REAR VIEW



Maytag Residential Maytag DE18CA Dryer Parts Parts Diagram 03 - REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	210385			Lock Nut For Adjustable Leg
003	210684			Foot, Adjustable Leg
004	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
005	211881			Grommet, Cord Part Not Used-Gas Models Only
006	NLA		Not Available	CONTROL COVER-WHITE
007	NLA		Not Available	CONTROL COVER-HARVEST WHEAT
008	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
009	Y302699	22003428		Leg, Adjustable
010	NLA		Not Available	CONTROL CENTER-WHITE
011	NLA		Not Available	CABINET-WHITE
012	NLA		Not Available	CABINET-ALMOND
013	NLA		Not Available	CABINET-HARVEST WHEAT
014	Y303361		Not Available	BASE ASSY. (UPPER &

014	Y303301	Not Available	LOWER)
015	NLA	Not Available	TOP COVER-WHITE
016	NLA	Not Available	TOP COVER-ALMOND
017	NLA	Not Available	TOP COVER-HARVEST WHEAT
018	Y303442		EXHAUST DUCT ASSEMBLY
019	NLA	Not Available	SCREW & WASHER ASSY.
020	NLA	Not Available	CONTROL COVER-WHITE
021	NLA	Not Available	CONTROL COVER-ALMOND
022	NLA	Not Available	CONTROL COVER-HARVEST WHEAT
023	Y305086		Adjustable Leg And Nut
024	310557		Washer
025	Y310632	1163839	Screw
026	NLA	Not Available	BACK FOR CONTROL PANEL
027	Y313559		Screw
028	Y313561		Screw---NA
029	Y314137		Foot, Rubber

