


# Maytag DE18CS 01 - FRONT VIEW



Maytag Residential Maytag DE18CS Dryer Parts Parts Diagram 01 - FRONT VIEW  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	<a href="#">62739</a>		Nut, Lock
002	204051	<a href="#">22204051</a>		Knob
003	<a href="#">204439</a>			Screw And Fstner Assembly
004	<a href="#">204445</a>			Screw And Fastener Assembly
005	205423	<a href="#">208883</a>		Coin Box K
006	205423L	<a href="#">208883</a>		Coin Box K
007	NLA		Not Available	MAYTAG COIN SLIDE
008	<a href="#">210385</a>			Lock Nut For Adjustable Leg
009	<a href="#">210684</a>			Foot, Adjustable Leg
010	212519	<a href="#">488234</a>		Screw 8-32 X 1/4
011	212949	<a href="#">22001866</a>		Screw, Relay
012	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
013	<a href="#">213099</a>			Lens For Control Panel
014	<a href="#">213949</a>			Screw, No.8-18 X 5/16 Inch
015	Y302699	<a href="#">22003428</a>		Leg, Adjustable
016	<a href="#">Y303204</a>			Start Switch With Nuts

017	NLA		Not Available	CABINET-WHITE
018	NLA		Not Available	CABINET-ALMOND
019	NLA		Not Available	CABINET-HARVEST WHEAT
020	NLA		Not Available	TOP COVER-WHITE
021	NLA		Not Available	TOP COVER-ALMOND
022	NLA		Not Available	TOP COVER-HARVEST WHEAT
023	Y303420		Not Available	SELECTOR SWITCH
024	<a href="#">Y303703</a>			Pilot Light
025	Y304577	<a href="#">33001230</a>		Hinge, Door
026	Y304579			DOOR (WHT)
027	NLA		Not Available	DOOR-ALMOND
028	NLA		Not Available	DOOR-HARVEST WHEAT
029	NLA		Not Available	FRONT PANEL-WHITE
030	NLA		Not Available	FRONT PANEL-ALMOND
031	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
032	NLA		Not Available	CONTROL COVER-WHITE
033	NLA		Not Available	CONTROL COVER-ALMOND
034	NLA		Not Available	CONTROL COVER-HARVEST WHEAT
035	NLA		Not Available	OUTER CASE-WHITE
036	NLA		Not Available	OUTER CASE-ALMOND
037	NLA		Not Available	OUTER CASE-HARVEST WHEAT---NA
038	<a href="#">Y305086</a>			Adjustable Leg And Nut
039	NLA		Not Available	KNOB AND SCREW
040	<a href="#">306436</a>			Door Latch Kit--W
041	<a href="#">Y312702</a>			Knurled Nut, Start Switch
042	<a href="#">Y313907</a>			Fastener, Twin
043	Y313908			DOOR PANEL-WHITE
044	NLA		Not Available	DOOR PANEL-ALMOND
045	NLA		Not Available	DOOR PANEL-HARVEST WHEAT
046	<a href="#">Y313910</a>			Clip, Door Liner To Outer Panel
047	NLA		Not Available	CONTROL PANEL
048	<a href="#">Y314062</a>			Screw, Door Hinge And Panel
049	<a href="#">Y314137</a>			Foot, Rubber
050	NLA		Not Available	SCREW FOR DOOR KNOB----NA

*the laundry company*<sup>®</sup>