


DE-DG18CT CT CONTROL CENTER COMPONENTS



Maytag Residential Maytag DE18CT Dryer Parts Parts Diagram 06 - CT CONTROL CENTER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	NLA		Not Available	OUTER CASE-WHITE
003	NLA		Not Available	OUTER CASE-ALMOND
004	NLA		Not Available	OUTER CASE-WHITE
005	NLA		Not Available	MTG. STRAP----NA
006	NLA		Not Available	ACCESS DOOR (WHITE)
007	NLA		Not Available	ACCESS DOOR-ALMOND
008	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
009	NLA		Not Available	ACCESS DOOR (WHITE)
010	NLA		Not Available	ACCESS DOOR-ALMOND
011	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
012	NLA		Not Available	HARNESS FOR TICKET CONTROL
013	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
014	212276	W10116760		Screw

015	NLA	Not Available	GASKET UNDER CONTROL CENTER
016	213089		Knob For Timer
017	NLA	Not Available	LATCH FOR ACCESS DOOR
018	Y302559	Not Available	HARNES FOR TIMER
019	NLA	Not Available	MAIN WIRE HARNES
020	Y303801	Not Available	TIMER WITH KNOB AND PIN
021	NLA	Not Available	CONTROL CENTER-WHITE
022	NLA	Not Available	CONTROL CENTER-ALMOND
023	NLA	Not Available	CONTROL CENTER-HARVEST WHEA
024	NLA	Not Available	TIMER MOTOR
025	NLA	Not Available	TIMER MOTOR
026	Y312300		Groov-Pin
027	910309		Washer, Mounting Strap

