

014	Y303879		Switch, Motor External Start
015	Y303945		IDLER SPRING ASSY. W/PLUG
016	Y305086		Adjustable Leg And Nut
017	Y305185	6-3051850	Pulley- MO
018	NLA	Not Available	SWITCH, MOTOR START- PROD.
019	NLA	Not Available	WIRE
020	306199		Relay, Heater
021	Y251119	3177991	Screw
022	Y310632	1163839	Screw
023	Y312527		Washer, Idler Shaft
024	Y312853		Cover For Thermostat Openin
025	Y312893		Housing, Blower
026	Y312894	315772	Sleeve, Idler Arm
027	NLA	Not Available	SUPPORT, MOTOR
028	Y312901		Seal, Housing Cover
029	312958	354987	Ring, Retaining
030	Y312959		Poly "V" Belt For Tumbler
031	Y312961	W10116751	Screw
032	312967		Clamp, Blower Housing
033	Y313262	W10116752	Retainer-
034	Y313561		Screw----NA
035	Y313582	W10116756	Spacer
036	Y313770		COVER FOR BLOWER HOUSING
037	Y314137		Foot, Rubber
038	410233	9703438	Ring-Retrn
039	410490		Spring, Retainer Wire Harness
040	901220		Ground Wire
041	910343	488234	Screw 8-32 X 1/4

