


## Maytag DE19CS 13 - 50HZ CONVERSION LIST



[Maytag Residential Maytag DE19CS Dryer Parts Parts Diagram 13 - 50HZ CONVERSION LIST](#)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	OUTER CASE-WHITE
002	NLA		Not Available	COIN METER WELD ASSEM - ALMON
003	NLA		Not Available	OUTER CASE-HARVEST WHEAT
004	<a href="#">211605</a>			Bezel, Timer Dial
005	NLA		Not Available	TIMER (240-50)
006	Y304656		Not Available	MOTOR (240V 50HZ)
007	<a href="#">305186</a>			Pulley, Motor
008	NLA		Not Available	PILOT LAMP
009	<a href="#">305812</a>			Timer
010	306527	<a href="#">305812</a>		Timer
011	<a href="#">Y313950</a>			Element, Heater