


Maytag DE24CA 05 - LINT SCREEN, TUMBLER (FRONT & BACK)



Maytag Residential Maytag DE24CA Dryer Parts Parts Diagram 05 - LINT SCREEN, TUMBLER (FRONT & BACK)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	205810			Wire, Ground
002	210720			Rivet, Bearing To Tumbler Frnt
003	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
004	Y303373	12001541		Drum Roller/Washer Assembly--W
005	306508			Tumbler Bearing Kit ----W
006	306656		Not Available	OUTLET DUCT & GRID ASSEMBLY
007	306657		Not Available	OUTLET DUCT & GRID
008	Y306660	33001106		Back, Tumbler
009	306663		Not Available	TUMBLER W/BAFFLES
010	Y306665	33001003		Screen, Lint
011	NLA		Not Available	TUMBLER FRONT----NA
012	Y310376			Clip, Door Switch Harness
013	310557			Washer
014	Y310632	1163839		Screw

015	Y310759		Screw, Tumbler Baffles
016	312535		Washer, Vault Mounting Brk.
017	312538	33001443	Nut, Hex
018	Y312948	6-3129480	Shaft- Tumbler
019	Y312959		Poly "V" Belt For Tumbler
020	Y312961	W10116751	Screw
021	Y312964	Not Available	OUTLET DUCT - OUTER HALF
022	Y313347	312535	Washer, Vault Mounting Brk.
023	Y313561		Screw----NA
024	NLA	Not Available	SCREW
025	Y313795		Guide For Lint Screen
026	Y313796		Lint Seal
027	NLA	Not Available	COVER, THREAD
028	Y314110	33002917	Screw, No.10-16
029	314158		Washer, Baffle To Tumbler
030	314802	Not Available	TUMBLER W/OUT BAFFLES
031	314803	33001012	Baffle
032	314803	33001012	Baffle
033	314804	33001004	Baffle, Tall
034	314820		Seal, Tumbler
035	410233	9703438	Ring-Retrn

