


# Maytag DE27CA 05 - FRONT PANEL & DOOR ASSEMBLY

SECTION: FRONT PANEL & DOOR ASSEMBLY  
 MODEL: DE-DG27CA



Issue Date: 10/90

28

Maytag Residential Maytag DE27CA Dryer Parts Parts Diagram 05 - FRONT PANEL & DOOR ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">314937</a>			Seal, Front Panel
002	NLA		Not Available	PART NOT USED
003	<a href="#">Y313907</a>			Fastener, Twin
004	<a href="#">204439</a>			Screw And Fstner Assembly
"	NLA		Not Available	PANEL, FRONT (WHT)
005	212982	<a href="#">22001650</a>		Fastener, Spring
006	<a href="#">Y310376</a>			Clip, Door Switch Harness
007	Y305753	<a href="#">W10169313</a>		Switch-Dor
008	314935	<a href="#">33001192</a>		Seal, Door
009	Y308070		Not Available	INNER DOOR W/GASKET
010	<a href="#">Y314062</a>			Screw, Door Hinge And Panel
011	<a href="#">308062</a>			Door Assembly Complete W/O Hinges
012	NLA		Not Available	DOOR OUTER HALF WHITE
013	NLA		Not Available	KNOB AND SCREW
014	314936	<a href="#">33001305</a>		Strike, Door
"	314944	<a href="#">33001305</a>		Strike, Door

015	<a href="#">Y313910</a>		Clip, Door Liner To Outer Panel
016	<a href="#">306436</a>		Door Latch Kit--W
017	NLA	Not Available	PART NOT USED
018	<a href="#">Y314025</a>		Latch For Access Door
019	<a href="#">312369</a>		Sleeve, Access Panel Stud Part Not Used
020	Y313340		LABEL, LINT SCREEN INSTRUCTION
021	314941	Not Available	LABEL, INSTRUCTION
022	NLA	Not Available	INSTRUCTION LABEL

