



[Maytag Residential Maytag DE27CS Dryer Parts Parts Diagram 13 - 50HZ CONVERSION LIST](#)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y304656		Not Available	MOTOR (240V 50HZ)
002	NLA		Not Available	INDICATOR LIGHT 240-50
003	305186			Pulley, Motor
004	305812			Timer
005	Y313950			Element, Heater

