


Maytag DE27CT 08 - FRONT PANEL & DOOR ASSEMBLY

SECTION: FRONT PANEL & DOOR ASSEMBLY

MODEL: DE-DG27CS-CT



Issue Date: 10/90

26

Maytag Residential Maytag DE27CT Dryer Parts Parts Diagram 08 - FRONT PANEL & DOOR ASSEMBLY
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|---------------|--------------------------------|
| 001 | 314937 | | | Seal, Front Panel |
| 002 | NLA | | Not Available | PART NOT USED |
| 003 | Y313907 | | | Fastener, Twin |
| 004 | 204439 | | | Screw And Fstner Assembly |
| " | NLA | | Not Available | PANEL, FRONT (WHT) |
| 005 | 212982 | 22001650 | | Fastener, Spring |
| 006 | Y310376 | | | Clip, Door Switch Harness |
| 007 | Y305753 | W10169313 | | Switch-Dor |
| 008 | 314935 | 33001192 | | Seal, Door |
| 009 | 308069 | | Not Available | DOOR, INNER W/GASKET |
| 010 | 307099 | 33001230 | | Hinge, Door |
| " | Y314062 | | | Screw, Door Hinge And Panel |
| 011 | NLA | | Not Available | DOOR, COMPLETE LESS HINGES (WH |
| 012 | 314967 | | Not Available | DOOR W/WINDOW OUTER HALF (WHT) |
| " | NLA | | Not Available | DOOR W/WIN CUT OUT |

| | | | |
|-----|-------------------------|--------------------------|--|
| | NLA | | OUTER ALMNA |
| 013 | 314939 | | Handle, Door |
| " | 314974 | | Handle, Door |
| " | 314975 | | Handle, Door |
| 014 | 314936 | 33001305 | Strike, Door |
| " | 314944 | 33001305 | Strike, Door |
| 015 | Y313910 | | Clip, Door Liner To Outer Panel |
| 016 | 306436 | | Door Latch Kit--W |
| 017 | NLA | Not Available | PART NOT USED |
| 018 | Y314025 | | Latch For Access Door |
| 019 | 312369 | | Sleeve, Access Panel Stud Part Not Used |
| 020 | Y313340 | | LABEL, LINT SCREEN INSTRUCTION |
| 021 | 314941 | Not Available | LABEL, INSTRUCTION |
| 022 | NLA | Not Available | INSTRUCTION LABEL |

