


Maytag DE306 02 - CABINET REMOVED



Maytag Residential Maytag DE306 Dryer Parts Parts Diagram 02 - CABINET REMOVED
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	014875		Not Available	CAP SCREW, No.14 X 1/2
2	015628		Not Available	BOLT, 5/16 X 3/4 HEX
3	015700		Not Available	CAP SCREW, 1/4-20 X 1/2
4	Y015825			Clip, Motor To Motor Support
5	051394		Not Available	BOLT, 5/16 X 2-1/8
6	052792			Screw, 1 1/4-20 X 5/16
7	Y053241			Set Screw, Motor Pulley
8	054865		Not Available	LOCK WASHER, 5/16 X 3/32
9	Y059131			Elbow, Venting
10	210385			Lock Nut For Adjustable Leg
11	210684			Foot, Adjustable Leg
12	211642		Not Available	SCREW, No.6-20 X 3/8 INCH
13	300831		Not Available	SHAFT AND SLIDE
14	300839		Not Available	SEAL
15	300840		Not Available	REDUCTION PULLEY
16	Y300844			Exhaust Housing

19	Y301120		Drum Pulley
20	301122	Y304596	Terminal Insulator Assembly
21	301123	Not Available	MOTOR PULLEY
22	301369	Not Available	SHAFT WITH SPIDER
23	Y302278		Motor
24	302535	Not Available	SUPPORT
25	302536	Not Available	BASE
26	Y302699	22003428	Leg, Adjustable
27	Y302815		Blower Housing With Bearing
28	302943		COVER WITH LINT SEAL-BLOWER
29	302954	Not Available	DRUM W/FELT - PORCELAIN
30	303709		Clip And Insulator Assembly
32	303846	22003781	Screw, Ground Strap
33	Y310376		Clip, Door Switch Harness
34	310578	Not Available	WASHER
35	Y310759		Screw, Tumbler Baffles
36	310768	Not Available	WASHER
37	310933	33002194	Nut, Speed
38	Y311012		Drive Belt
39	Y311013		Motor Belt
40	311019	Y311946	Heater Wire 240 Volt
41	311093		Washer, Terminal Connection
42	311265		Spring
43	311324		Motor Base
44	311534		Felt Seal
45	Y311538		Carbon Brush Holder
46	Y312057	910624	Screw
48	Y313404	Y301120	Drum Pulley
49	211642	Not Available	SCREW, No.6-20 X 3/8 INCH
50	251117	Not Available	LOCK WASHER
51	301467	Not Available	SLIP RING
52	301542	Not Available	WIRE HARNESS FOR DRUM
53	Y303877	Not Available	SWITCH, MOTOR EXTERNAL START No.303358-2, No.303358-4, 303358-7
54	Y303879		Switch, Motor External Start
55	306208	Y302278	Motor
56	310204	Not Available	SNAP RING
57	310262		Washer
58	310579	Not Available	SCREW, No.10-24 X 11/16 INCH
59	311048	Not Available	WASHER, ALUMINUM
61	311484	112432	Nut
62	Y311539		Spring For Carbon Brush
63	311540	Not Available	COVER FOR CARBON BRUSH
64	Y311542	Not Available	CARBON BRUSH
65	311546	911445	Wire Connector
66	810148	Not Available	SCREW