


Maytag DE309 01 - CONTROL PANEL & COMPONENTS



Maytag Residential Maytag DE309 Dryer Parts Parts Diagram 01 - CONTROL PANEL & COMPONENTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211168	W10139210		Screw, 8-18 X 5/16
2	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	213063	703431		Palnut
4	213077		Not Available	CAP FOR TIMER KNOB
5	213322		Not Available	MAYTAG DECAL
6	213323			Fastener, Exhaust Duct Kit
7	214468		Not Available	BRACKET-LEFT HAND
8	214469		Not Available	BRACKET-RIGHT HAND
9	303360		Not Available	TOP COVER-WHITE
10	303360A		Not Available	TOP COVER-DARK AVOCADO
11	303360B		Not Available	TOP COVER-DARK COPPERTONE
12	303360G		Not Available	TOP COVER-DARK GOLD
13	303360L		Not Available	TOP COVER-ALMOND
14	303360M		Not Available	TOP COVER-HARVEST WHEAT

15	303360N	Not Available	TOP COVER-FRESH AVOCADO
16	304078	Not Available	TIMER DIAL, SUN-GLOW
17	Y304104		Buzzer
18	304105	Not Available	BUZZER HARNESS
19	304125	Not Available	CONTROL PANEL, SUN-GLOW
20	Y304585		Timer Motor RPR For 305214 Timer Only
21	Y304585		Timer Motor RPR For 305214 Timer Only
22	304646	Not Available	TIMER MOTOR
23	Y305020	Not Available	TIMER
24	305080	Not Available	WIRE HARNESS
25	312243	Not Available	CONTROL COVER-WHITE
26	312243B	Not Available	CONTROL COVER-DK COPPERTONE
27	312243G	Not Available	CONTROL COVER-DARK GOLD
28	312243L	Not Available	CONTROL COVER-ALMOND
29	312243M	Not Available	CONTROL COVER-HARVEST WHEAT
30	312243N	Not Available	CONTROL COVER-FRESH AVOCADO
31	312273		Nut, Control Knob
32	312852		Selector Knob-Clear Acrylic
33	Y313588	488234	Screw 8-32 X 1/4
34	313819	Not Available	BACK-UP PLATE
35	410351	Not Available	HARNESS RETAINER

the laundry company[®]

the laundry company[®]