


Maytag DE313 07 - REAR VIEW



28

Maytag [Residential Maytag DE313 Dryer Parts](#) Parts Diagram 07 - REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	400008			Block, Terminal
2	Y313561			Screw---NA
3	Y312184			Strap, Grounding
4	311484	112432		Nut
5	Y312905		Not Available	COVER, TERMINAL
6	Y311423	489483		Screw 10-32 X 1/2
7	Y310632	1163839		Screw
8	Y311270			Washer, Terminal Block
9	Y312209	W10001200		Screw
10	Y312904			Bracket, Terminal Block
14	215075			Fastener, Control Panel To Console
15	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
16	Y305193			Console
17	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY

18	301548		Clamp, Ground Wire
19	311155		Ground Wire And Clamp
20	Y313559		Screw
21	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
22	Y312951	Not Available	ACCESS COVER, BACK
23	Y305086		Adjustable Leg And Nut
24	Y314137		Foot, Rubber
25	Y052740	62739	Nut, Lock
26	Y303361	Not Available	BASE ASSY. (UPPER & LOWER)
27	213007		Xfor Cabinet See Cabinet, Back
28	305302	Not Available	CABINET-WHITE
29	307104		Top Cover Assembly
30	303846	22003781	Screw, Ground Strap

