


Maytag DE382 03 - FRONT VIEW



Maytag [Residential Maytag DE382 Dryer Parts](#) Parts Diagram 03 - FRONT VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y052740	62739		Nut, Lock
2	204439			Screw And Fstner Assembly
3	204445			Screw And Fastener Assembly
4	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
5	213007			Xfor Cabinet See Cabinet, Back
6	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
7	303942		Not Available	KNOB AND SCREW
8	304595	3369903		Dishrack
11	Y305086			Adjustable Leg And Nut
12	Y305190	307104		Top Cover Assembly
15	Y305193			Console
18	305302		Not Available	CABINET-WHITE
21	Y306668			DOOR (WHT)
24	Y310632	1163839		Screw

