


# Maytag DE4000 01 - CONTROL PANEL

SECTION: CONTROL PANEL  
MODEL: DE-DG4000



Issue Date: 6/90

2

Maytag [Residential Maytag DE4000 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">314184</a>			Back Up Plate
2	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
3	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
"	305205	<a href="#">694419</a>		Mini-Buzzer
4	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
"	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
5	<a href="#">306483</a>			Timer
"	910708	<a href="#">488234</a>		Screw 8-32 X 1/4
"	308088		Not Available	TIMER
6	<a href="#">214897</a>			Pad, Control Panel
7	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
"	314727	<a href="#">207927</a>		End Cap, Control Panel
8	<a href="#">214894</a>			Fastener, End Cap
9	314723	<a href="#">W10133501</a>		Cap, Knob

10	<a href="#">312273</a>		Nut, Control Knob
11	<a href="#">314724</a>		Knob For Timer
12	314725	<a href="#">33001500</a>	Dial, Timer Indicator
13	307747	Not Available	CONTROL PANEL
"	<a href="#">Y308093</a>		Control Panel Assembly
"	<a href="#">210932</a>		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
14	307254	Not Available	WIRE HARNESS
"	307261	Not Available	WIRE HARNESS
"	308085	Not Available	WIRE HARNESS
"	Y308087	Not Available	WIRE HARNESS
15	314726	Not Available	END CAP - LEFT HAND
16	211168	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
"	<a href="#">307305</a>		Switch Push To Start

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>