


# Maytag DE4000 02 - FRONT PANEL & DOOR ASSEMBLY

SECTION: FRONT PANEL & DOOR ASSEMBLY  
 MODEL: DE-DG MODELS



Issue Date: 8/92

Maytag [Residential Maytag DE4000 Dryer Parts](#) Parts Diagram 02 - FRONT PANEL & DOOR ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314942			INSTRUCTION LABEL
2	314941		Not Available	LABEL, INSTRUCTION
3	<a href="#">Y314062</a>			Screw, Door Hinge And Panel
"	307099	<a href="#">33001230</a>		Hinge, Door
4	<a href="#">314946</a>			Handle White
5	Y307111		Not Available	DOOR ASSY. COMPLETE (WHT)
6	<a href="#">314966</a>			Panel, Outer
7	<a href="#">306436</a>			Door Latch Kit-W
8	212982	<a href="#">22001650</a>		Fastener, Spring
9	<a href="#">Y310376</a>			Clip, Door Switch Harness
10	Y305753	<a href="#">W10169313</a>		Switch-Dor
11	<a href="#">314937</a>			Seal, Front Panel
12	<a href="#">Y313907</a>			Fastener, Twin
13	<a href="#">308000</a>			Panel, Front
17	314936	<a href="#">33001305</a>		Strike, Door
"	314944	<a href="#">33001305</a>		Strike, Door

18	314935	<a href="#">33001192</a>	Seal, Door
19	307098	Not Available	DOOR, INNER (W/SEAL)
20	<a href="#">Y313910</a>		Clip, Door Liner To Outer Panel

