


# Maytag DE406 03 - CONTROL PANEL & COMPONENTS



Maytag [Residential Maytag DE406 Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL & COMPONENTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205198		Not Available	BRACKET KIT - LEFT HAND
2	205199		Not Available	BRACKET KIT - RIGHT HAND
3	205415	<a href="#">279347</a>		Switch-Lid
4	<a href="#">210745</a>			Wire Terminal
5	<a href="#">211065</a>			Spring, Index Wheel
6	<a href="#">211252</a>			Screw, Ground Wire
7	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
8	<a href="#">211410</a>			Screw, HeX Head No.8 X 3/8 Inch
9	<a href="#">211605</a>			Bezel, Timer Dial
10	211737	<a href="#">248562</a>		Terminal
11	212220	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
12	213077		Not Available	CAP FOR TIMER KNOB
13	<a href="#">213099</a>			Lens For Control Panel
14	<a href="#">213323</a>			Fastener, Exhaust Duct Kit
15	Y302454	<a href="#">33302454</a>		Timer

16	302469	Not Available	HARNES FOR SHROUD
17	302501	Not Available	HARNES
19	<a href="#">Y302829</a>		Timer Dial And Knob
20	302934	Not Available	CONTROL PANEL WITH LENS
21	303088	Not Available	GAS VALVE WIRES WITH PLUG
22	Y304106	Not Available	TIMER DIAL & KNOB, SUN-GLOW
23	304125	Not Available	CONTROL PANEL, SUN-GLOW
24	304127	Not Available	CONTROL PANEL KIT, SEA-MIST
25	304128	<a href="#">WB2X9652</a>	Insulation
26	<a href="#">Y304585</a>		Timer Motor RPR For 305214 Timer Only
27	<a href="#">Y310376</a>		Clip, Door Switch Harness
28	<a href="#">Y312140</a>		Wire Connector
29	312257	Not Available	BRACKET
30	<a href="#">312258</a>		Actuator
31	312261	Not Available	WASHER
32	<a href="#">Y312270</a>		Clip, Spring Retainer
33	<a href="#">312303</a>		Spring
34	313562	Not Available	BACK-UP PLATE
35	410351	Not Available	HARNES RETAINER

