



[Maytag Residential Maytag DE50 Dryer Parts](#) Parts Diagram 04 - CABINET, DRUM & MOTOR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	014875		Not Available	CAP SCREW, No.14 X 1/2
2	Y015825			Clip, Motor To Motor Support
3	Y053241			Set Screw, Motor Pulley
4	Y055980			Hi-Temp Adhesive, 2 Oz Tube
5	204314		Not Available	POLY LUBE - 4 OZ
6	211252			Screw, Ground Wire
7	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
8	302831		Not Available	CABINET-WHITE
9	302836		Not Available	IDLER PULLEY WITH BEARINGS
10	302844		Not Available	HARNES FOR MOTOR AND THERM.
11	Y302845		Not Available	MOTOR 120-60
12	Y302853		Not Available	FELT SEAL - REAR
13	302921		Not Available	DRUM DRIVE PULLEY W/SCREW
14	302932		Not Available	PORCELAIN DRUM

14	302932	Not Available	W/PLUGS
15	302941	Not Available	BACK PANEL W/BLOWER HOUSING
16	302991	Not Available	MOTOR 240-50
17	303160	Not Available	MOTOR HARNESS
18	303189		Rear Bearing Support
19	303784		Drive Pulley
20	310557		Washer
21	311339	Not Available	SET SCREW
22	312505		Motor Support
23	312516	Not Available	SHAFT FOR IDLER PULLEY
24	312517	Not Available	BRACKET FOR IDLER PULLEY
25	312518	Not Available	SPRING FOR IDLER
26	Y312527		Washer, Idler Shaft
27	312529	Not Available	GRIP RING-IDLER PULLEY SHAF
28	312544		Poly V Belt 3 Vee
29	312606	4332752	Clip
30	Y313328	Not Available	POLY V BELT
31	312643	Not Available	RETENTION WIRE-IDLER BRACKE

