

Maytag DE612 02 - DOOR



30

Maytag [Residential Maytag DE612 Dryer Parts](#) Parts Diagram 02 - DOOR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	Y313927			INSTRUCTION LABEL
3	306436			Door Latch Kit-W
4	314286			Seal For Front Panel
5	Y310376			Clip, Door Switch Harness
6	212982	22001650		Fastener, Spring
7	314077			Door Seal
8	314347	400021-1		Screw
9	Y305754	W10169313		Switch-Dor
10	Y314062			Screw, Door Hinge And Panel
11	Y313910			Clip, Door Liner To Outer Panel
12	Y313911			Door Strike Retainer
13	303942		Not Available	KNOB AND SCREW
14	Y313908			DOOR PANEL-WHITE
15	Y304579			DOOR (WHT)
"	Y306668			DOOR (WHT)
				INNER DOOR WITH KNOB &

16	305835	Not Available	INNER DOOR WITH KNOB & SCRE
"	306676	Not Available	INNER DOOR WITH KNOB
17	302542	Not Available	PART NOT USED. (DG ONLY)
18	Y304577	33001230	Hinge, Door
19	Y313907		Fastener, Twin
20	304595	3369903	Dishrack
21	204439		Screw And Fstner Assembly

