



[Maytag Residential Maytag DE700 Dryer Parts](#) Parts Diagram 06 - HEATING ELEMENT, WIRING & CONTROLS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	300537		Not Available	No.27 WIRE
2	300546		Not Available	No.28 WIRE WITH TERMINALS
3	300552		Not Available	LAMP SOCKET
4	Y300858	<a href="#">305865</a>		High Limit Thermostat-W
5	Y300859	<a href="#">305864</a>		Thermostat Kit
6	<a href="#">Y300896</a>			No.2 Wire
7	300900	<a href="#">W10311986</a>		Dishrack
8	300902		Not Available	No.13 WIRE WITH TERMINALS
9	300909	<a href="#">8009</a>		Bulb-Light
10	300910		Not Available	RECEPTACLE
11	300911		Not Available	LAMP RECEPTACLE
12	<a href="#">Y301007</a>			Thermostat
13	301018		Not Available	No.22 WIRE WITH TERMINALS
14	301019		Not Available	No.21 WIRE WITH TERMINALS

15	301020		Not Available	No.20 WIRE WITH TERMINALS
16	301037	<a href="#">400008</a>		Block, Terminal
17	301122	<a href="#">Y304596</a>		Terminal Insulator Assembly
18	301130		Not Available	TIMER
19	301181		Not Available	SHROUD WIRE HARNESS
20	<a href="#">Y301336</a>			Door Switch
21	301342		Not Available	WIRING HARNESS FOR DOOR SWITCH
22	301393	<a href="#">303709</a>		Clip And Insulator Assembly
23	301432		Not Available	TEMPERATURE SWITCH-GRAY
24	310154		Not Available	TERMINAL FOR MOTOR
25	<a href="#">310207</a>			Screw, No.6 X 1/4 Inch
26	310292		Not Available	SCREW-TERMINAL BLOCK TO BRKT
27	<a href="#">Y310376</a>			Clip, Door Switch Harness
28	310543		Not Available	OZONE LAMP-4 WATT
29	Y310632	<a href="#">1163839</a>		Screw
30	310844	<a href="#">W10068250</a>		Screw
31	311055		Not Available	SUPPORT FOR OZONE LAMP
32	<a href="#">311155</a>			Ground Wire And Clamp
33	311179		Not Available	SWITCH BRACKET
34	311259		Not Available	SCREW, No.4-36 X 1/2 INCH
35	<a href="#">Y311270</a>			Washer, Terminal Block
36	<a href="#">311551</a>			Clip For Door Harness
37	Y311916	<a href="#">22003781</a>		Screw, Ground Strap
38	311944	<a href="#">Y311946</a>		Heater Wire 240 Volt
39	312206		Not Available	TERMINAL BRACKET
40	200862		Not Available	BALLAST
41	201110		Not Available	WIRE CONNECTOR
42	201580		Not Available	SWITCH FOR FLUORESCENT LAMP
43	210310	<a href="#">31001575</a>		Bulb, Cylinder Light
44	210887	<a href="#">12990527</a>		Screw-Sm/Hex
45	<a href="#">211252</a>			Screw, Ground Wire
46	301393	<a href="#">303709</a>		Clip And Insulator Assembly
47	301432		Not Available	TEMPERATURE SWITCH-GRAY
48	310154		Not Available	TERMINAL FOR MOTOR
49	<a href="#">310207</a>			Screw, No.6 X 1/4 Inch
50	310292		Not Available	SCREW-TERMINAL BLOCK TO BRKT
51	<a href="#">Y310376</a>			Clip, Door Switch Harness
52	310543		Not Available	OZONE LAMP-4 WATT
53	Y310632	<a href="#">1163839</a>		Screw
54	310844	<a href="#">W10068250</a>		Screw
55	311055		Not Available	SUPPORT FOR OZONE LAMP
56	<a href="#">311155</a>			Ground Wire And Clamp
57	311179		Not Available	SWITCH BRACKET
58	311259		Not Available	SCREW, No.4-36 X 1/2 INCH
59	<a href="#">Y311270</a>			Washer, Terminal Block
60	<a href="#">311551</a>			Clip For Door Harness
61	Y311916	<a href="#">22003781</a>		Screw, Ground Strap

62	311944	<a href="#">Y311946</a>	Heater Wire 240 Volt
63	312206		Not Available
			TERMINAL BRACKET
64	200862		Not Available
			BALLAST
65	201110		Not Available
			WIRE CONNECTOR
66	201580		Not Available
			SWITCH FOR FLUORESCENT LAMP
67	210310	<a href="#">31001575</a>	Bulb, Cylinder Light
68	210887	<a href="#">12990527</a>	Screw-Sm/Hex
69	<a href="#">211252</a>		Screw, Ground Wire
70	211737	<a href="#">248562</a>	Terminal
71	<a href="#">Y014872</a>		Screw, Coin Meter Stop -
72	Y052684	<a href="#">112432</a>	Nut
73	<a href="#">054151</a>		Screw, No.4-40 X 1/4

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>