



[Maytag Residential Maytag DE701 Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y300538		Not Available	FLUORESCENT LAMP
2	300541		Not Available	COVER FOR CONTROL PANEL
3	300552		Not Available	LAMP SOCKET
4	<a href="#">301010</a>			Chime
5	301462		Not Available	TIMER
6	301465		Not Available	ELECTRONIC CONTROL
7	301487		Not Available	CIRCUIT BOARD HARNESS
8	301489		Not Available	WIRE HARNESS FOR MOTOR
9	301553		Not Available	WIRE HARNESS
10	301690		Not Available	CAPACITOR 8.0 MICROFARADS
11	<a href="#">Y310376</a>			Clip, Door Switch Harness
12	310744		Not Available	SCREW-LAMP RECEPTACLE TO BRACK
13	310844	<a href="#">W10068250</a>		Screw
14	311259		Not Available	SCREW, No.4-36 X 1/2 INCH

15	311503		Not Available	CONTROL PANEL
16	311504		Not Available	GLASS PANEL-LEFT HAND, GOLD
17	Y311505		Not Available	GLASS PANEL-RIGHT HAND, GOL
18	311535		Not Available	TIMER DIAL
19	311543		Not Available	CONTROL PANEL PL
20	311608	<a href="#">98165</a>		Screw
21	311612		Not Available	COVER, CIRCUIT BOARD TERMINALS
22	311613	<a href="#">Y311711</a>		Screw, Fuse Block
23	312074		Not Available	BRACKET F/ELECTRONIC CONTRO
24	200860		Not Available	RECEPTACLE FOR LAMP-RIGHT
25	200862		Not Available	BALLAST
26	201580		Not Available	SWITCH FOR FLUORESCENT LAMP
27	202807		Not Available	RECEPT FOR FLUORESCENT LAMP
28	210310	<a href="#">31001575</a>		Bulb, Cylinder Light
29	<a href="#">211065</a>			Spring, Index Wheel
30	211238		Not Available	PANEL BRACKET, LEFT
31	211239		Not Available	PANEL BRACKET, RIGHT
32	211244		Not Available	GASKET
33	211246		Not Available	SPRING CLIP
34	211247		Not Available	RETAINER
35	211249		Not Available	FASTENER
36	<a href="#">211250</a>			Fastener
37	<a href="#">211252</a>			Screw, Ground Wire
38	211293		Not Available	SCREW, No.8 X 1/2 INCH
39	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
40	<a href="#">211410</a>			Screw, HeX Head No.8 X 3/8 Inch
41	211512		Not Available	WASHER
42	211836		Not Available	CONTROL KNOB - T
43	213077		Not Available	CAP FOR TIMER KNOB
44	052727		Not Available	HEX. NUT, 1/4-28
45	410351		Not Available	HARNES RETAINER

