


# Maytag DE712 07 - REAR VIEW



28

Maytag [Residential Maytag DE712 Dryer Parts](#) Parts Diagram 07 - REAR VIEW  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">400008</a>			Block, Terminal
2	<a href="#">Y313561</a>			Screw---NA
3	<a href="#">Y312184</a>			Strap, Grounding
4	311484	<a href="#">112432</a>		Nut
5	Y312905		Not Available	COVER, TERMINAL
6	Y311423	<a href="#">489483</a>		Screw 10-32 X 1/2
7	Y310632	<a href="#">1163839</a>		Screw
8	<a href="#">Y311270</a>			Washer, Terminal Block
9	Y312209	<a href="#">W10001200</a>		Screw
10	<a href="#">Y312904</a>			Bracket, Terminal Block
14	<a href="#">215075</a>			Fastener, Control Panel To Console
15	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
16	<a href="#">Y305193</a>			Console
17	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY

18	<a href="#">301548</a>		Clamp, Ground Wire
19	<a href="#">311155</a>		Ground Wire And Clamp
20	<a href="#">Y313559</a>		Screw
21	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
22	Y312951	Not Available	ACCESS COVER, BACK
23	<a href="#">Y305086</a>		Adjustable Leg And Nut
24	<a href="#">Y314137</a>		Foot, Rubber
25	Y052740	<a href="#">62739</a>	Nut, Lock
26	Y303361	Not Available	BASE ASSY. (UPPER & LOWER)
27	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
28	305302	Not Available	CABINET-WHITE
29	<a href="#">307104</a>		Top Cover Assembly
30	303846	<a href="#">22003781</a>	Screw, Ground Strap

