


Maytag DE7500 07 - LINT SCREEN, TUMBLER (FRONT & BACK)

SECTION: LINT SCREEN, TUMBLER, TUMBLER FRONT & BACK
 MODEL: DE-DG MODELS



Issue Date: 6/90

44

Maytag Residential Maytag DE7500 Dryer Parts Parts Diagram 07 - LINT SCREEN, TUMBLER (FRONT & BACK)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y307112	33001016		Outlet Duct Assembly
"	Y314110	33002917		Screw, No.10-16
2	Y307107	33002970		Lint Filte
3	Y310632	1163839		Screw
"	307109	33001179		Front, Tumbler
"	Y313561			Screw----NA
"	313764		Not Available	SCREW
4	Y310376			Clip, Door Switch Harness
5	313915	31-3915		Tech Sheet
8	314820			Seal, Tumbler
9	Y310759			Screw, Tumbler Baffles
"	314803	33001012		Baffle
10	314158			Washer, Baffle To Tumbler
11	314802		Not Available	TUMBLER W/OUT BAFFLES
12	Y307114	33001178		Back, Tumbler
"	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

13	312538	33001443	Nut, Hex
14	Y313347	312535	Washer, Vault Mounting Brk.
15	Y312948	6-3129480	Shaft- Tumbler
16	Y303373	12001541	Drum Roller/Washer Assembly--W
17	312535		Washer, Vault Mounting Brk.
18	410233	9703438	Ring-Retrn
19	Y312959		Poly "V" Belt For Tumbler
20	Y310759		Screw, Tumbler Baffles
"	314804	33001004	Baffle, Tall
21	210720		Rivet, Bearing To Tumbler Frnt
22	306508		Tumbler Bearing Kit ---W
27	Y312658		Receptacle, Sensor Ground Wire

the laundry company[®]

lows
the laundry company[®]

lows
the laundry company[®]