


Maytag DE806 03 - CONTROL PANEL & COMPONENTS



Maytag Residential Maytag DE806 Dryer Parts Parts Diagram 03 - CONTROL PANEL & COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	052690		Not Available	HEX. NUT, No.10-32
2	052792			Screw, 1 1/4-20 X 5/16
3	054157		Not Available	SCREW, No.10-32 X 1/4
4	200862		Not Available	BALLAST
5	201838			Starter Socket
6	201840	92790		Starter
7	202807		Not Available	RECEPT FOR FLUORESCENT LAMP
8	205198		Not Available	BRACKET KIT - LEFT HAND
9	205199		Not Available	BRACKET KIT - RIGHT HAND
10	210745			Wire Terminal
11	211065			Spring, Index Wheel
12	211168	W10139210		Screw, 8-18 X 5/16
13	211252			Screw, Ground Wire
14	211286		Not Available	SCREW, HEX HD No.8 X 1/2 INCH
15	211294	00767		Screw, 8A X 3/8 HeX Washer

			Head Tapping
16	211410		Screw, HeX Head No.8 X 3/8 Inch
17	211642	Not Available	SCREW, No.6-20 X 3/8 INCH
18	211737	248562	Terminal
19	213077	Not Available	CAP FOR TIMER KNOB
20	214884	213501	Screw, No.6-20 X 1-1/8 Inch
21	Y300538	Not Available	FLUORESCENT LAMP
22	301464	Not Available	BAFFLE FOR DRUM
23	301467	Not Available	SLIP RING
24	301542	Not Available	WIRE HARNESS FOR DRUM
25	301962	Not Available	SOCKET FOR LAMP
26	302469	Not Available	HARNESS FOR SHROUD
27	302470	302470MAY	Harness
28	302471	Not Available	HARNESS
29	302471	Not Available	HARNESS
30	302472	W10339879	Tie, Cable
31	302505	Not Available	HARNESS
32	302524	Not Available	BRACKET
33	Y302528	33302528	Switch- CO
34	Y302543	Not Available	SPRING ASSEMBLY
35	302553	Not Available	SHAFT
37	303040		Main Wire Harness
39	303042	Y0303042	Venturi TU
40	303043	Not Available	BAFFLE LEAD WIRE
41	Y303045		Baffle Assembly
42	303049	Not Available	ELECTRONIC CONTROL
43	303054	Not Available	CONTROL HARNESS
44	303109	Not Available	TIMER DIAL
45	Y303250	Not Available	CAPACITOR 15.0 MICROFARADS
46	Y303771	Not Available	CHIME ACTUATOR ASSEMBLY
47	Y304080		Selection Dial, Sun-Glow
48	305181	Not Available	CAPACITOR
49	Y310376		Clip, Door Switch Harness
50	310578	Not Available	WASHER
51	310579	Not Available	SCREW, No.10-24 X 11/16 INCH
52	Y310759		Screw, Tumbler Baffles
53	310768	Not Available	WASHER
54	Y311538		Carbon Brush Holder
55	Y311539		Spring For Carbon Brush
56	311540	Not Available	COVER FOR CARBON BRUSH
57	Y311542	Not Available	CARBON BRUSH
58	311546	911445	Wire Connector
59	311548		Insulation Sleeve, 1-1/4 Inc
60	Y311550	Not Available	SPADE (MINIATURE)
61	311612	Not Available	COVER, CIRCUIT BOARD TERMINALS
62	311613	Y311711	Screw, Fuse Block
63	Y311660		Chime
64	311924	Not Available	CLAMP RETAINER
65	311925	Not Available	CLAMP FOR CAPACITOR

66	Y312057	910624		Screw
67	312074		Not Available	BRACKET F/ELECTRONIC CONTRO
68	Y312140			Wire Connector
69	Y312247			Wire
70	Y312260		Not Available	LINK
71	312267		Not Available	GLASS - RIGHT
72	Y312268			Glass - Left
73	312273			Nut, Control Knob
74	Y312280			Bearing
75	312282		Not Available	PLATE
76	Y312300			Groov-Pin
77	312693		Not Available	BRACKET
78	312852			Selector Knob-Clear Acrylic
79	Y313321			Chime Actuator
80	400015		Not Available	SOLENOID
81	410351		Not Available	HARNES RETAINER

