


# Maytag DE808 01 - CONTROL PANEL & COMPONENTS



Maytag [Residential Maytag DE808 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL & COMPONENTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	201110		Not Available	WIRE CONNECTOR
3	<a href="#">201838</a>			Starter Socket
4	201840	<a href="#">92790</a>		Starter
5	202807		Not Available	RECEPT FOR FLUORESCENT LAMP
6	210587	<a href="#">W10116760</a>		Screw
7	<a href="#">211065</a>			Spring, Index Wheel
8	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
9	<a href="#">211250</a>			Fastener
10	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
11	<a href="#">211410</a>			Screw, HeX Head No.8 X 3/8 Inch
12	212220	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
13	213023		Not Available	RETAINER
14	213026		Not Available	CLIP
15	213077		Not Available	CAP FOR TIMER KNOB

16	213117	<a href="#">67006908</a>		Screw, Ice Rack
17	213322		Not Available	MAYTAG DECAL
18	<a href="#">213323</a>			Fastener, Exhaust Duct Kit
19	214468		Not Available	BRACKET-LEFT HAND
20	Y300538		Not Available	FLUORESCENT LAMP
21	301962		Not Available	SOCKET FOR LAMP
22	302524		Not Available	BRACKET
23	Y302543		Not Available	SPRING ASSEMBLY
24	302553		Not Available	SHAFT
25	Y303350		Not Available	SOLENOID
26	303360		Not Available	TOP COVER-WHITE
27	303360A		Not Available	TOP COVER-DARK AVOCADO
28	303360B		Not Available	TOP COVER-DARK COPPERTONE
29	303360G		Not Available	TOP COVER-DARK GOLD
30	303360L		Not Available	TOP COVER-ALMOND
31	303360M		Not Available	TOP COVER-HARVEST WHEAT
32	303360N		Not Available	TOP COVER-FRESH AVOCADO
33	Y303771		Not Available	CHIME ACTUATOR ASSEMBLY
34	<a href="#">304081</a>			Timer Dial
35	304472		Not Available	TEMPERATURE SWITCH
36	Y304473		Not Available	CONTROL SWITCH
37	Y304478		Not Available	PRINTED CIRCUIT BOARD ASSM.
38	<a href="#">Y304671</a>			Button Kit
39	<a href="#">304980</a>			Edgeboard Connector Assembl
40	<a href="#">304983</a>			Main Wire Harness
42	305187		Not Available	TUMBLER W/BAFFLES
43	Y310632	<a href="#">1163839</a>		Screw
44	Y311423	<a href="#">489483</a>		Screw 10-32 X 1/2
45	<a href="#">Y311660</a>			Chime
46	Y312260		Not Available	LINK
47	312267		Not Available	GLASS - RIGHT
48	<a href="#">Y312268</a>			Glass - Left
49	<a href="#">312273</a>			Nut, Control Knob
50	<a href="#">Y312280</a>			Bearing
51	312282		Not Available	PLATE
52	<a href="#">312852</a>			Selector Knob-Clear Acrylic
53	<a href="#">313823</a>			Control Panel
54	314118	<a href="#">31-4118</a>		Tech Sheet