


Maytag DE8600 01 - CONTROL PANEL

SECTION: CONTROL PANEL
MODEL: DE-DG8600



Issue Date: 6/90

28

Maytag [Residential Maytag DE8600 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314184			Back Up Plate
2	214872			Palnut, End Cap Note: Nut, Lamp Holder
3	307305			Switch Push To Start
"	211168	W10139210		Screw, 8-18 X 5/16
4	211168	W10139210		Screw, 8-18 X 5/16
"	207365			2 Button Switch
5	305205	694419		Mini-Buzzer
"	211168	W10139210		Screw, 8-18 X 5/16
6	307310			Press Care Switch
"	211168	W10139210		Screw, 8-18 X 5/16
7	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	204807			Ground Wire, Supp. Plte To Top Cover
8	306545			Timer
"	910708	488234		Screw 8-32 X 1/4

9	214897		Pad, Control Panel
10	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
"	207216	Not Available	END CAP RH
11	214894		Fastener, End Cap
12	215821	Not Available	CAP, KNOB
13	312273		Nut, Control Knob
14	315041		Knob, Timer
15	315042		Dial Skirt
16	307323		Control Panel
"	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
17	307252	Not Available	WIRE HARNESS NA
"	307270	Not Available	WIRE HARNESS
18	207215	Not Available	END CAP LH

