


Maytag DE9800 01 - CONTROL PANEL

SECTION: CONTROL PANEL
MODEL: DE-DG9800



Issue Date: 6/90

32

Maytag [Residential Maytag DE9800 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314184			Back Up Plate
2	214872			Palnut, End Cap Note: Nut, Lamp Holder
3	307898		Not Available	ELECTRONIC CONTROL
"	211168	W10139210		Screw, 8-18 X 5/16
4	307897			Edge Board Connector
"	311863		Not Available	SCREW FOR CAUTION PLATE---NA
5	Y251119	3177991		Screw
"	307899			Relay
6	Y307896			Pc Board
7	307305			Switch Push To Start
"	211168	W10139210		Screw, 8-18 X 5/16
8	307304		Not Available	TEMP CONTROL SWITCH 3 BUTTON
"	213117	67006908		Screw, Ice Rack
9	306916			Resistor, Med Temp Elec

10	213117	67006908		Screw, Ice Rack
"	307304		Not Available	TEMP CONTROL SWITCH 3 BUTTON
11	Y305204		Not Available	BUZZER - ADJUSTABLE
"	211168	W10139210		Screw, 8-18 X 5/16
12	211168	W10139210		Screw, 8-18 X 5/16
"	314169	313610		Hndle-Door
13	314171		Not Available	PIVOT ARM FOR BUZZER
14	307364		Not Available	SLIDE ASSY
15	204807			Ground Wire, Supp. Pltte To Top Cover
"	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
16	Y307404			Timer
"	910708	488234		Screw 8-32 X 1/4
17	214897			Pad, Control Panel
18	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
"	207216		Not Available	END CAP RH
19	214894			Fastener, End Cap
20	215821		Not Available	CAP, KNOB
21	312273			Nut, Control Knob
22	315041			Knob, Timer
23	315042			Dial Skirt
24	307321		Not Available	CONTROL PANEL
25	Y307269			Wire Harness
"	307256		Not Available	WIRE HARNESS
26	307422		Not Available	WIRE HARNESS
27	207215		Not Available	END CAP LH

the laundry company[®]

lows
the laundry company[®]