


Maytag DG100PN1 05 - MAIN DOOR SWITCH ASSEMBLY



Maytag Residential Maytag DG100PN1 Dryer Parts Parts Diagram 05 - MAIN DOOR SWITCH ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A313208	W10146840		100 120 Ma
002	A150415		Not Available	SCREW, CRIMPTITE (PH. RD.HD.) (No.10-16 X 1/2" PH. RD. HD.)
003	A152003	152003		3 8-32 X 1
004	A137006		Not Available	SWITCH, DOOR
005	A121028	121028		1 4 X.032
006	A121027	121027		.187 X .03
007	A170210	170210		35 Hinge
008	A122626	122626		15P Umnl C
009	A122705	122705		Umnl Sok 2