


Maytag DG100PN1 12 - DSI BURNER ASSEMBLY



Maytag [Residential Maytag DG100PN1 Dryer Parts](#) Parts Diagram 12 - DSI BURNER ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A850853	850853		100 DSI B
002	A128926		Not Available	MODULE, DSI ONLY
003	A150299	150299		10 X 1 H
004	A880134		Not Available	IGNITER/FLAME PROBE KIT ASSY (INCLUDES No.4 & 5)
005	A150415		Not Available	SCREW, CRIMPTITE (PH. RD.HD.) (No.10-16 X 1/2" PH. RD. HD.)
006	A141107		Not Available	BURNER, RIBBON
007	A318318	318318		100 Bumer
008	A150415		Not Available	SCREW, CRIMPTITE (PH. RD.HD.) (No.10-16 X 1/2" PH. RD. HD.)
009	A141208		Not Available	MANIFOLD, 3-PORT
010	A318316	318316		100 Burn
				SCREW, CRIMPTITE (PH.

011	A150415		Not Available	RD.HD.) (No.10-16 X 1/2` PH. RD. HD.)
012	A318317	318317		Ud80 AD100
013	A150415		Not Available	SCREW, CRIMPTITE (PH. RD.HD.) (No.10-16 X 1/2` PH. RD. HD.)
014	A128928	W10149182		Redundant
015	A318317	318317		Ud80 AD100
016	A150415		Not Available	SCREW, CRIMPTITE (PH. RD.HD.) (No.10-16 X 1/2` PH. RD. HD.)
017	A142703	142703		1 2 X 4 BL
018	A142511	142511		1 2 X 3 4
019	A142701	142701		3 4 Close
020	A142601	142601		3 4 Black
021	A142701	142701		3 4 Close
022	A141300			3 4 GAS S
023	A142821	142821		3 4 X 36 B
024	A140830	140830		Burner Ori

