



[Maytag Residential Maytag DG101 Dryer Parts Parts Diagram 05 - FRONT VIEW](#)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	300588		Not Available	PANEL COVER
2	300589		Not Available	TOP COVER
3	300592		Not Available	HINGE
4	300595		Not Available	KNOB AND DIAL
5	<a href="#">300838</a>			Lint Screen
6	300895	<a href="#">3369903</a>		Dishrack
7	<a href="#">301023</a>			Lint Screen Retainer
8	301119		Not Available	CABINET WITH HINGES
9	301285		Not Available	GAS VALVE - NATURAL
10	301290		Not Available	ACCESS DOOR
11	<a href="#">Y301320</a>			Door Switch---NA
12	301369		Not Available	SHAFT WITH SPIDER
13	301404	<a href="#">12001114</a>		Kit- LP GA
14	301417	<a href="#">33301414</a>		Timer
15	<a href="#">301457</a>			Door-White
16	302093	<a href="#">675659</a>		Gasket

17	<a href="#">Y302278</a>		Motor
18	302521	Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
19	302954	Not Available	DRUM W/FELT - PORCELAIN
20	<a href="#">302984</a>		Baffle Assembly - Poly
21	310217	Not Available	No Longer Available
22	<a href="#">310219</a>		No.10z Fastener
23	<a href="#">310551</a>		Fastener
24	310579	Not Available	SCREW, No.10-24 X 11/16 INCH
25	Y310632	<a href="#">1163839</a>	Screw
26	310774	Not Available	CABINET TRIM
27	310775	Not Available	TRIM RETAINER
28	310779	<a href="#">4330903</a>	Knob Surf
29	<a href="#">Y310780</a>		Strike Button
30	310844	<a href="#">W10068250</a>	Screw
31	310934	<a href="#">22003428</a>	Leg, Adjustable
32	310935	Not Available	FASTENER
33	<a href="#">Y311012</a>		Drive Belt
34	311015	Not Available	DOOR SEAL
35	<a href="#">Y311017</a>		Retainer Spring
36	311033	Not Available	RUBBER SLEEVE
37	<a href="#">311036</a>		Nylon Stud
38	<a href="#">311155</a>		Ground Wire And Clamp
39	311298	<a href="#">4391991</a>	Switch-Inf
40	<a href="#">Y311413</a>		Dyalon Washer
41	<a href="#">311414</a>		Latch Bracket
42	311419	Not Available	CONTROL BRACKET
43	<a href="#">311420</a>		Pilot Tube
44	311434	<a href="#">31-1434</a>	Miniman
45	311492	Not Available	LEVER FOR MANUEL RESET
46	311493	Not Available	HINGE PIN FOR MANUEL RESET LVR
47	Y311499	<a href="#">W10068260</a>	Screw
48	311502	Not Available	BACK FOR CABINET
49	311614	Not Available	SCREW FOR DOOR RECESS
50	312024	Not Available	OVERLAY FOR TEMP. CONTROL
51	312025	Not Available	CONTROL PANEL
52	Y312060	Not Available	SHIELD FOR SPIDER---C
53	312207	Not Available	TERMINAL COVER
54	210294	<a href="#">910309</a>	Washer, Mounting Strap
55	<a href="#">210385</a>		Lock Nut For Adjustable Leg
56	210442	Not Available	WASHER NYLON
57	<a href="#">210609</a>		Nylon Washer
58	<a href="#">210684</a>		Foot, Adjustable Leg
59	210865	Not Available	FASTENER
60	211114	Not Available	RETAINER FOR TRIM
61	<a href="#">211196</a>		Acorn Nut
62	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
63	211343	Not Available	SPRING FASTENER
64	<a href="#">211739</a>		Screw, Cabinet To Base
65	<a href="#">211881</a>		Grommet, Cord Part Not Used-Gas Models Only

66	211970	Not Available	SCREW-TOP COVER TO CABINET
67	212014	Not Available	MEDALLION
68	053654	Not Available	SCREW, No.5-40 X 3/8
69	054580	Not Available	SCREW, No.10-32 X 1/4
70	<a href="#">Y059128</a>		Standard 4" Vent Kit
71	Y059129	<a href="#">4396007RW</a>	Vent Hood
72	<a href="#">Y059130</a>		Pipe, Venting
73	<a href="#">Y059131</a>		Elbow, Venting
74	059133	Not Available	ALUMINUM WINDOW 4X12X18
75	Y059134		PLATE, ALUM. WINDOW (15``X20``)
76	038766	Not Available	HOLE SAW W/DRILL BIT

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>