


Maytag DG107 02 - FRONT PANEL & DOOR ASSEMBLY



Maytag Residential Maytag DG107 Dryer Parts Parts Diagram 02 - FRONT PANEL & DOOR ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	204439			Screw And Fstner Assembly
2	212949	22001866		Screw, Relay
3	212982	22001650		Fastener, Spring
4	302542		Not Available	PART NOT USED. (DG ONLY)
5	302542H		Not Available	ACCESS DOOR-SHADED GOLD
6	302542K		Not Available	ACCESS DOOR-SHADED AVOCADO
7	302542L		Not Available	PART NOT USED. (DG ONLY)
8	302542M		Not Available	ACCESS DOOR-HARVEST WHEAT
9	302542N		Not Available	ACCESS DOOR-FRESH AVOCADO
10	303942		Not Available	KNOB AND SCREW
11	Y304577	33001230		Hinge, Door
12	Y304579			DOOR (WHT)
13	304579F		Not Available	DOOR-LIGHT GOLD
14	304579J		Not Available	DOOR-LIGHT AVOCADO

15	304579L		Not Available	DOOR-ALMOND
16	304579M		Not Available	DOOR-HARVEST WHEAT
17	304579N		Not Available	DOOR-FRESH AVOCADO
18	304594			Front Panel-White
19	304594H		Not Available	FRONT PANEL-SHADED GOLD
20	304594K		Not Available	FRONT PANEL-SHADED AVOCADO
21	304594L		Not Available	FRONT PANEL-ALMOND
22	304594M	3369903		Dishrack
23	304594N		Not Available	FRONT PANEL-FRESH AVOCADO
24	305835		Not Available	INNER DOOR WITH KNOB & SCRE
25	306436			Door Latch Kit--W
26	Y310376			Clip, Door Switch Harness
27	312301		Not Available	BUSHING FOR ACCESS STUD
28	312369			Sleeve, Access Panel Stud Part Not Used
29	Y313340			LABEL, LINT SCREEN INSTRUCTION
30	Y313907			Fastener, Twin
31	Y313908			DOOR PANEL-WHITE
32	313908F		Not Available	DOOR PANEL-LIGHT GOLD
33	313908J		Not Available	DOOR PANEL-LIGHT AVOCADO
34	313908L		Not Available	DOOR PANEL-ALMOND
35	313908M		Not Available	DOOR PANEL-HARVEST WHEAT
36	313908N		Not Available	DOOR PANEL-FRESH AVOCADO
37	Y313910			Clip, Door Liner To Outer Panel
38	Y313911			Door Strike Retainer
39	Y313927			INSTRUCTION LABEL
40	Y314062			Screw, Door Hinge And Panel
41	314077			Door Seal
42	314119		Not Available	GAS IGNITION LABEL
43	314286			Seal For Front Panel
44	314347	400021-1		Screw
45	Y304575	W10169313		Switch-Dor

the laundry company[®]