


Maytag DG110 08 - REAR VIEW

MODELS DE-DG110-210-410-510-610-710-810 REAR VIEW



Maytag [Residential Maytag DG110 Dryer Parts](#) Parts Diagram 08 - REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y052740	62739		Nut, Lock
2	Y201808			Converter
3	204439			Screw And Fstner Assembly
4	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
5	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	211881			Grommet, Cord Part Not Used- Gas Models Only
7	213007			Xfor Cabinet See Cabinet, Back
8	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
9	215075			Fastener, Control Panel To Console
10	301548			Clamp, Ground Wire
11	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY

12	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
13	303846	22003781		Screw, Ground Strap
14	304594			Front Panel-White
20	Y305086			Adjustable Leg And Nut
21	Y305190	307104		Top Cover Assembly
24	Y305193			Console
27	305302		Not Available	CABINET-WHITE
30	Y310632	1163839		Screw
31	311155			Ground Wire And Clamp
32	Y312905		Not Available	COVER, TERMINAL
33	Y312951		Not Available	ACCESS COVER, BACK
34	313122			Screw - Baffle To Tumbler
35	Y313559			Screw
36	Y314137			Foot, Rubber
"	Y313561			Screw---NA

