


Maytag DG16CA 01 - FRONT VIEW



Maytag Residential Maytag DG16CA Dryer Parts Parts Diagram 01 - FRONT VIEW

Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|------------------------|--------------------------|---------------|-----------------------|
| 001 | NLA | | Not Available | MAYTAG COIN SLIDE |
| 002 | 300838 | | | Lint Screen |
| 003 | 301023 | | | Lint Screen Retainer |
| 004 | NLA | | Not Available | SHAFT WITH SPIDER |
| 005 | NLA | | Not Available | DOOR HINGE ON CABINET |
| 006 | 301746 | Y304298 | | Hinge - Lower |
| 007 | NLA | | Not Available | HINGE ASSEMBLY---N |
| 008 | NLA | | Not Available | DOOR LINER |
| 009 | NLA | | Not Available | DOOR-WHITE |
| 010 | NLA | | Not Available | CONTROL COVER-WHITE |
| 011 | NLA | | Not Available | LATCH |
| 012 | NLA | | Not Available | FRONT PANEL-WHITE |
| 013 | NLA | | Not Available | TOP COVER-WHITE |
| 014 | NLA | | Not Available | ACCESS DOOR (WHITE) |
| 015 | NLA | | Not Available | PILOT LIGHT |
| 016 | Y302699 | 22003428 | | Leg, Adjustable |

| | | | | |
|-----|-------------------------|---------------------------|---------------|-----------------------------------------|
| 017 | NLA | | Not Available | DRUM W/FELT - PORCELAIN |
| 018 | NLA | | Not Available | BAFFLE ASSEMBLY - POLY |
| 019 | Y303224 | | | Selector Switch |
| 020 | NLA | | Not Available | NO LONGER AVAILABLE |
| 021 | NLA | | Not Available | WASHER |
| 022 | NLA | | Not Available | SCREW, No.10-24 X 11/16 INCH |
| 023 | Y310759 | | | Screw, Tumbler Baffles |
| 024 | NLA | | Not Available | WASHER |
| 025 | Y311017 | | | Retainer Spring |
| 026 | NLA | | Not Available | SCREW |
| 027 | 311534 | | | Felt Seal |
| 028 | NLA | | Not Available | CLIP FOR DOOR HARNESS |
| 029 | Y312060 | | Not Available | SHIELD FOR SPIDER---C |
| 030 | NLA | | Not Available | DRYING INSTRUCTION OVERLAY |
| 031 | NLA | | Not Available | PANEL-WHITE |
| 032 | NLA | | Not Available | PANEL-WHITE |
| 033 | 312238 | | | Door Seal |
| 034 | NLA | | Not Available | DOOR PANEL-WHITE |
| 035 | NLA | | Not Available | STRIKE PLATE |
| 036 | NLA | | Not Available | BACK FOR CONTROL PANEL |
| 037 | NLA | | Not Available | ANGLE FOR CABINET - DRYER |
| 038 | NLA | | Not Available | CONTROL PANEL |
| 039 | NLA | | Not Available | HANDLE |
| 040 | NLA | | Not Available | BUSHING FOR ACCESS STUD |
| 041 | Y312304 | 22001866 | | Screw, Relay |
| 042 | NLA | | Not Available | SCREW---NA |
| 043 | NLA | | Not Available | INSULATION - DOOR |
| 044 | 312369 | | | Sleeve, Access Panel Stud Part Not Used |
| 045 | NLA | | Not Available | MAGNETIC LATCH RETAINER |
| 046 | 312622 | 22001496 | | Front Panel Fastener And Screw |
| 047 | Y312702 | | | Knurled Nut, Start Switch |
| 048 | Y312706 | 422617 | | Nut |
| 049 | Y312744 | | | Door Panel-White |
| 050 | 312751 | | | Lockwasher, Start Switch |
| 051 | NLA | | Not Available | CONTROL PANEL |
| 052 | NLA | | Not Available | CONTROL PANEL |
| 053 | 204051 | 22204051 | | Knob |
| 054 | NLA | | Not Available | COIN BOX-WHITE---NA |
| 055 | 210385 | | | Lock Nut For Adjustable Leg |
| 056 | 210684 | | | Foot, Adjustable Leg |
| 057 | 211294 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 058 | 212276 | W10116760 | | Screw |
| 059 | 212519 | 488234 | | Screw 8-32 X 1/4 |
| 060 | 213007 | | | Xfor Cabinet See Cabinet, Back |
| 061 | 213099 | | | Lens For Control Panel |
| 062 | 213322 | | Not Available | MAYTAG DECAL |
| 063 | 213949 | | | Screw, No.8-18 X 5/16 Inch |

| | | | |
|-----|-------------------------|---------------|-----------------------------|
| 064 | NLA | Not Available | SCREW, 1 1/4-20 X 5/16 |
| 065 | NLA | Not Available | SCREW, No.4-40 X 1/4 |
| 066 | 214650 | | Screw For 2-4051 Knob |
| 067 | Y301336 | | Door Switch |
| 068 | Y302455 | | Switch |
| 069 | Y303204 | | Start Switch With Nuts |
| 070 | Y303318 | | Switch Assembly With Hex Nu |

