


Maytag DG18CA 07 - FRONT PANEL-REAR VIEW



Maytag [Residential Maytag DG18CA Dryer Parts](#) Parts Diagram 07 - FRONT PANEL-REAR VIEW
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SCREW, No.4-40 X 1/4
002	Y055978			Rubber Adhesive, 2 Oz Tube
003	204439			Screw And Fstner Assembly
004	212949	22001866		Screw, Relay
005	212982	22001650		Fastener, Spring
006	NLA		Not Available	HINGE ASSEMBLY----N
007	NLA		Not Available	ACCESS DOOR (WHITE)
008	NLA		Not Available	ACCESS DOOR-ALMOND
009	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
010	NLA		Not Available	DOOR COMPLETE-WHITE
011	NLA		Not Available	DOOR COMPLETE-HARVEST WHEAT
012	NLA		Not Available	FRONT PANEL-WHITE
013	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
014	Y304298			Hinge - Lower

015	NLA	Not Available	HINGE - UPPER
016	NLA	Not Available	HINGE - LOWER
017	NLA	Not Available	HINGE - UPPER
018	310560	74004005	Screw, 6-32 X 5/16"
019	NLA	Not Available	STRIKE PLATE
020	NLA	Not Available	BUSHING FOR ACCESS STUD
021	312369		Sleeve, Access Panel Stud Part Not Used
022	NLA	Not Available	DOOR PANEL-WHITE
023	NLA	Not Available	DOOR PANEL-HAVEST WHEAT
024	Y312891	Not Available	DOOR LINER - INNER HALF
025	Y313340		LABEL, LINT SCREEN INSTRUCTION
026	Y313927		INSTRUCTION LABEL
027	314077		Door Seal
028	NLA	Not Available	GAS IGNITION LABEL
029	314286		Seal For Front Panel