


Maytag DG18CM 09 - FRONT PANEL-REAR VIEW



Maytag Residential Maytag DG18CM Dryer Parts Parts Diagram 09 - FRONT PANEL-REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SCREW, No.4-40 X 1/4
002	Y055978			Rubber Adhesive, 2 Oz Tube
003	204439			Screw And Fstner Assembly
004	212949	22001866		Screw, Relay
005	212982	22001650		Fastener, Spring
006	NLA		Not Available	HINGE ASSEMBLY----N
007	NLA		Not Available	ACCESS DOOR (WHITE)
008	NLA		Not Available	ACCESS DOOR-ALMOND
009	NLA		Not Available	DOOR COMPLETE-WHITE
010	NLA		Not Available	DOOR COMPLETE-HARVEST WHEAT
011	Y303441		Not Available	DOOR SWITCH
012	NLA		Not Available	FRONT PANEL-WHITE
013	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
014	Y304298			Hinge - Lower
015	NLA		Not Available	HINGE - UPPER

016	NLA	Not Available	HINGE - LOWER
017	NLA	Not Available	HINGE - UPPER
018	310560	74004005	Screw, 6-32 X 5/16"
019	NLA	Not Available	STRIKE PLATE
020	NLA	Not Available	BUSHING FOR ACCESS STUD
021	312369		Sleeve, Access Panel Stud Part Not Used
022	NLA	Not Available	DOOR PANEL-WHITE
023	NLA	Not Available	DOOR PANEL-WHITE
024	NLA	Not Available	DOOR PANEL-HAVEST WHEAT
025	Y312891	Not Available	DOOR LINER - INNER HALF
026	Y313340		LABEL, LINT SCREEN INSTRUCTION
027	Y313927		INSTRUCTION LABEL
028	314077		Door Seal
029	NLA	Not Available	GAS IGNITION LABEL
030	314286		Seal For Front Panel

