


DE-DG18CT CT CONTROL CENTER COMPONENTS



Maytag Residential Maytag DG18CT Dryer Parts Parts Diagram 06 - CT CONTROL CENTER  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	<a href="#">62739</a>		Nut, Lock
002	NLA		Not Available	OUTER CASE-WHITE
003	NLA		Not Available	OUTER CASE-ALMOND
004	NLA		Not Available	OUTER CASE-HARVEST WHEAT
005	NLA		Not Available	MTG. STRAP----NA
006	NLA		Not Available	ACCESS DOOR (WHITE)
007	NLA		Not Available	ACCESS DOOR-ALMOND
008	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
009	NLA		Not Available	ACCESS DOOR (WHITE)
010	NLA		Not Available	ACCESS DOOR-ALMOND
011	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
012	NLA		Not Available	HARNES FOR TICKET CONTROL
013	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping

014	212276	<a href="#">W10116760</a>		Screw
015	NLA		Not Available	GASKET UNDER CONTROL CENTER
016	<a href="#">213089</a>			Knob For Timer
017	NLA		Not Available	LATCH FOR ACCESS DOOR
018	Y302559		Not Available	HARNES FOR TIMER
019	NLA		Not Available	MAIN WIRE HARNES
020	Y303801		Not Available	TIMER WITH KNOB AND PIN
021	NLA		Not Available	CONTROL CENTER-WHITE
022	NLA		Not Available	CONTROL CENTER-ALMOND
023	NLA		Not Available	CONTROL CENTER-HARVEST WHEA
024	NLA		Not Available	TIMER MOTOR
025	NLA		Not Available	TIMER MOTOR
026	<a href="#">Y312300</a>			Groov-Pin
027	<a href="#">910309</a>			Washer, Mounting Strap

