


Maytag DG21CM 10 - LINT SCREEN, TUMBLER (FRONT & BACK)

MODELS DE-DG21CA-CM-CS-CT

LINT SCREEN, TUMBLER, TUMBLER FRONT & TUMBLER BACK



Maytag Residential Maytag DG21CM Dryer Parts Parts Diagram 10 - LINT SCREEN, TUMBLER (FRONT & BACK)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y053241			Set Screw, Motor Pulley
002	Y055978			Rubber Adhesive, 2 Oz Tube
003	204807			Ground Wire, Supp. Plte To Top Cover
004	210720			Rivet, Bearing To Tumbler Frmt
005	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
006	Y303373	12001541		Drum Roller/Washer Assembly--W
007	Y303815	33001231		Front- Tumbler
008	Y304244			Motor Pulley With Set Screw
009	Y304384	33001003		Screen, Lint
010	Y304648	33001106		Back, Tumbler
011	Y305185	6-3051850		Pulley- MO
012	305187		Not Available	TUMBLER W/BAFFLES
013	Y310376			Clip, Door Switch Harness
014	310557			Washer

015	Y310632	1163839		Screw
016	Y310759			Screw, Tumbler Baffles
017	NLA		Not Available	WASHER
018	312535			Washer, Vault Mounting Brk.
019	312538	33001443		Nut, Hex
020	Y312907			Tumbler Baffle
021	312940	306508		Tumbler Bearing Kit ----W
022	312941	306508		Tumbler Bearing Kit ----W
023	Y312948	6-3129480		Shaft- Tumbler
024	Y312959			Poly "V" Belt For Tumbler
025	Y312961	W10116751		Screw
026	Y312964		Not Available	OUTLET DUCT - OUTER HALF
027	Y313347	312535		Washer, Vault Mounting Brk.
028	Y313541	33313541		Seal- Tumbler
029	Y313561			Screw----NA
030	Y313794		Not Available	OUTLET GRID AND DUCT --- S
031	Y313795			Guide For Lint Screen
032	Y313796			Lint Seal
033	Y314110	33002917		Screw, No.10-16
034	Y314153		Not Available	TUMBLER No.
035	NLA		Not Available	TUMBLER BAFFLE - SHORT
036	314155	33001004		Baffle, Tall
037	314158			Washer, Baffle To Tumbler
038	410233	9703438		Ring-Retrn

the laundry company[®]

the laundry company[®]