


Maytag DG21CT 11 - LINT SCREEN, TUMBLER (FRONT & BACK)

MODELS DE-DG21CA-CM-CS-CT

LINT SCREEN, TUMBLER, TUMBLER FRONT & TUMBLER BACK



Maytag Residential Maytag DG21CT Dryer Parts Parts Diagram 11 - LINT SCREEN, TUMBLER (FRONT & BACK)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y053241			Set Screw, Motor Pulley
002	Y055978			Rubber Adhesive, 2 Oz Tube
003	204807			Ground Wire, Supp. Plte To Top Cover
004	210720			Rivet, Bearing To Tumbler Frmt
005	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
006	Y303373	12001541		Drum Roller/Washer Assembly--W
007	Y303815	33001231		Front- Tumbler
008	Y304244			Motor Pulley With Set Screw
009	Y304648	33001106		Back, Tumbler
010	Y305185	6-3051850		Pulley- MO
011	305187		Not Available	TUMBLER W/BAFFLES
012	Y310376			Clip, Door Switch Harness
013	310557			Washer
014	Y310632	1163839		Screw

015	Y310759		Screw, Tumbler Baffles
016	NLA	Not Available	WASHER
017	312535		Washer, Vault Mounting Brk.
018	312538	33001443	Nut, Hex
019	Y312907		Tumbler Baffle
020	312940	306508	Tumbler Bearing Kit ---W
021	312941	306508	Tumbler Bearing Kit ----W
022	Y312948	6-3129480	Shaft- Tumbler
023	Y312959		Poly "V" Belt For Tumbler
024	Y312961	W10116751	Screw
025	Y312964	Not Available	OUTLET DUCT - OUTER HALF
026	Y313347	312535	Washer, Vault Mounting Brk.
027	Y313541	33313541	Seal- Tumbler
028	Y313561		Screw----NA
029	Y313794	Not Available	OUTLET GRID AND DUCT --- S
030	Y314110	33002917	Screw, No.10-16
031	Y314153	Not Available	TUMBLER No.
032	NLA	Not Available	TUMBLER BAFFLE - SHORT
033	314155	33001004	Baffle, Tall
034	314158		Washer, Baffle To Tumbler
035	410233	9703438	Ring-Retrn

