


Maytag DG22CA 05 - LINT SCREEN, TUMBLER (FRONT & BACK)

MODELS DE-DG22CA-CS-CT

LINT SCREEN, TUMBLER, TUMBLER FRONT & TUMBLER BACK



Maytag [Residential Maytag DG22CA Dryer Parts](#) Parts Diagram 05 - LINT SCREEN, TUMBLER (FRONT & BACK)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y055978			Rubber Adhesive, 2 Oz Tube
002	205810			Wire, Ground
003	210720			Rivet, Bearing To Tumbler Fmt
004	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
005	Y303373	12001541		Drum Roller/Washer Assembly--W
006	Y303815	33001231		Front- Tumbler
007	Y304384	33001003		Screen, Lint
008	Y304648	33001106		Back, Tumbler
009	Y304810		Not Available	OUTLET DUCT ASSEMBLY---S
010	305187		Not Available	TUMBLER W/BAFFLES
011	Y310376			Clip, Door Switch Harness
012	310557			Washer
013	Y310632	1163839		Screw
014	Y310759			Screw, Tumbler Baffles

015	312535		Washer, Vault Mounting Brk.
016	312538	33001443	Nut, Hex
017	312940	306508	Tumbler Bearing Kit ---W
018	312941	306508	Tumbler Bearing Kit ---W
019	Y312948	6-3129480	Shaft- Tumbler
020	Y312959		Poly "V" Belt For Tumbler
021	Y312961	W10116751	Screw
022	Y312964	Not Available	OUTLET DUCT - OUTER HALF
023	Y313347	312535	Washer, Vault Mounting Brk.
024	Y313541	33313541	Seal- Tumbler
025	Y313561		Screw---NA
026	NLA	Not Available	SCREW
027	Y313795		Guide For Lint Screen
028	Y313796		Lint Seal
029	NLA	Not Available	COVER, THREAD
030	Y314110	33002917	Screw, No.10-16
031	Y314153	Not Available	TUMBLER No.
032	NLA	Not Available	TUMBLER BAFFLE - SHORT
033	314155	33001004	Baffle, Tall
034	314158		Washer, Baffle To Tumbler
035	410233	9703438	Ring-Retrn

