


Maytag DG22CT 01 - FRONT VIEW



Maytag [Residential Maytag DG22CT Dryer Parts](#) Parts Diagram 01 - FRONT VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	204439			Screw And Fstner Assembly
003	204445			Screw And Fastener Assembly
004	210684			Foot, Adjustable Leg
005	211168	W10139210		Screw, 8-18 X 5/16
006	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
007	213007			Xfor Cabinet See Cabinet, Back
008	NLA		Not Available	ACCESS DOOR (WHT)
009	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
010	NLA		Not Available	SPACER ASSY (WHT)
011	NLA		Not Available	NAME PLATE, CONTROL PANEL
012	NLA		Not Available	FRONT PANEL (WHT)
013	304965			Door Complete-White
"	NLA		Not Available	(ALM)

014	Y305087	22003544	Adjustable Leg W/Foot And Nut
015	NLA		Not Available (ALM)
"	Y305190	307104	Top Cover Assembly
016	NLA		Not Available CABINET (WHT)
017	NLA		Not Available CABINET (WHT)
018	NLA		Not Available INNER DOOR W/KNOB & SCREW
019	NLA		Not Available KNOB & SCREW
020	Y310632	1163839	Screw
021	310933	33002194	Nut, Speed
022	Y313559		Screw
023	NLA		Not Available (ALM)
"	Y313946		Not Available DOOR PANEL-WHITE
024	NLA		Not Available TOP COVER PLATE
025	NLA		Not Available SCREW
026	910768	M0280301	Tie Electr

